



**Installation Instructions:**

1. Place and screw the Lock Body on the edge of the door jamb or box as shown.
2. Place and screw the edge of the hinge plate on the door or lid as shown. Make sure that the parts do not rub on each other when opening and closing the door or lid.

**Instrucciones de Instalación:**

1. Coloque y atornille el cerrojo en la orilla de la jamba o caja como se muestra.
2. Coloque y atornille la orilla de la bisagra en la puerta o tapa como se muestra. Asegurese que las partes no se tallen con una y otra cuando abran o cierren la puerta o tapadera.

Pro-Lok® And Entry Armor™ Are Trademarks Of Weinraub Enterprises, Inc. © 2009. [www.ENTRYARMOR.com](http://www.ENTRYARMOR.com)

Item # ELK-111-C



6 38246 31087 6

Need A Special Item? Visit Our Website  
For Custom Requests And New Product  
Additions.