



1. Close window tightly.
2. Place lock on the edge of wood as shown. Make sure that there is just enough clearance so that the window can be opened and closed without the lock half's rubbing on each other.
3. Drill pilot holes and install screws.

Note:

You may need to shim one half of the lock so that they are level with each other. You can use anything such as a washer, wood, small piece of cardboard.

-
1. Cierre la ventana firmemente.
 2. Coloque la cerradura en la orilla de la madera como se muestra. Asegurese que las dos mitades tengan un mínimo de espacio y no peguen cuando se abra y cierre la ventana.
 3. Taladre los agujeros de guía e instale los tornillos.

Nota: Tal vez necesitara usar una cuña en alguna de las dos mitades de la cerradura para que estén debidamente alineadas. Puede usar una rondana, madera, o un pedazo de cartón.

Pro-Lok® And Entry Armor™ Are Trademarks Of Weinraub Enterprises, Inc. © 2009. www.ENTRYARMOR.com

Item # EWL-111-B



6 38246 31101 9

Need A Special Item? Visit Our Website
For Custom Requests And New Product
Additions.

Made in China