



1. Close window tight.
2. Loosen both thumb screw and place window lock on track snug against the back of the window as shown.
3. Tighten thumb screw tight on track

Although not as secure as installing the lock with the window fully closed, you may open the window slightly for ventilation and install the lock.

TIP: Install a lock on the top and bottom track for added security.

TIP: Consult your Security Consultant on how to prevent your window from being lifted out of the track. Easy methods such as installing a screw in the top track may prevent the window from being lifted out.

-
1. Cierre la ventana firmemente.
 2. Afloje el tornillo de orejas y coloque la cerradura en la guía corredora pegado en la parte trasera de la ventana como se muestra.
 3. Apriete el tornillo de orejas en la guía corredora.

Aunque no es tan seguro como instalar la cerradura con la ventana completamente cerrada, puede abrir la ventana un poco para ventilación e instalar la cerradura.

Recomendación: Instale una cerradura en la parte de arriba y la parte de abajo para mayor seguridad.

Recomendación: Pregúntele a su consultor de seguridad como prevenir que su ventana sea levantada y sacada de la guía corredora. Algunos métodos sencillos como instalar un tornillo en la parte de arriba de la guía corredora previene que la ventana pueda ser levantada.

Pro-Lok® And Entry Armor® Are Trademarks Of Weinraub Enterprises, Inc. © 2011. www.ENTRYARMOR.com

Item # EWL-150-AL



6 38246 31103 3